



## SB.11W PARKING BARRIER

### INSTALLATION AND USER INSTRUCTIONS

Read in full before starting

#### SAFETY

We recommend the following minimum precautions are taken:

- Wear appropriate safety clothing.
- Eye protection and hand protection should be worn, including safety helmet.
- Wear strong protective gloves.
- Secure the site from pedestrians and vehicles, where applicable, by the use of high visibility tape, barriers, cones, safety lamps etc.
- If you use a power supply ensure that it is secure and in a safe dry location.
- Ensure there are no underground services that may be affected.
- A minimum of two personnel are recommended.

#### INSTALLATION INSTRUCTIONS

- Determine the position of the installation and ensure the surface is suitable – preferably concrete at least 250mm x 250mm x 150mm deep.
- Use the bolt holes in the flange plate for a template and drill holes for the bolts.
- Bolt the post/bollard into position with the under surface of the flange resting flat on the ground, making sure the bolts are securely tightened.
- The drilling hole depth and diameter will depend on the type of bolt being used. Fixing down bolts is available extra – type depends on ground conditions.

**If you have eyelets please ensure they are facing the desired orientation before the posts are fixed in position**

#### MAINTENANCE

- Occasionally clean all surfaces with soap and water
- Check all fixing bolts and other visible fixings are suitably tight and have not worked loose.
- Check foundations remain firm.