

SB.23 SINGLE LEAF HEIGHT RESTRICTION BARRIER

INSTALLATION AND USER INSTRUCTIONS

Read in full before starting

- Determine the correct position of Height Restriction Barrier
- Two rootings should be dug out 500mm square 800mm deep to accommodate hinge posts at the correct width
- The hinge posts should be buried into the ground 760mm to achieve correct height clearance
- The posts are now ready to be concreted in.
- The posts must be supported until the concrete cures.
- Once cured the height restrictor leaves can be hung on the posts and adjusted so the two leaves clap together correctly using the adjustable hinges
- Make sure sliding bolt operates correctly sliding into the two saddles on the opposite leaf
- If latch back posts are to be fitted determine the correct position and again dig out footings at 500mm square 800mm deep.
- Make sure that the gates open back and latch bars fit in catch properly, concrete the posts in correct position making sure the posts are square and support if necessary until concrete has cured.