




SB.2P PARKING BARRIER

INSTALLATION INSTRUCTIONS

(Read in full before starting)



BASE: 305mm x 290mm

Four fixing bolts required

Powder Coated Yellow

Padlock facility (Padlock not supplied)



SAFETY

- Wear appropriate safety clothing
- Eye protection and hand protection should be worn, including safety helmet
- Wear strong protective gloves
- Secure the site from pedestrians and vehicles, where applicable by the use of high visibility tape, barrier, cones and safety lamps etc
- If you use power supply ensure that it is secure and safe in a dry location
- Ensure there are no underground services that may be affected
- A minimum of two personnel are recommended

INSTALLATION INSTRUCTIONS

- The SB.2 padlock base has a socket on the underside of the base 110 x 65 x 50mm deep this needs to be taken into consideration when casting the plinth, determine the position of the post first.
- Foundations should be dug out to accommodate 400mm cube of concrete, depth of concrete can be reduced dependent on what surface block is cast into.
- After the concrete has been poured push a wooden block slightly bigger than the dimensions of the base plate socket into the centre of the wet plinth. This can be removed once the concrete has cured and will accommodate the socket of the underside of the base plate.
- Once concrete has cured remove wooden block with chisel and place SB.2p barrier in position plinth. The base plate should sit flat and level with ground surface and can be used as a template to drill fixing holes/
- Four 12mm holes should now be drilled in concrete plinth 100mm deep. The base plate can now be secured with four m14 x 75mm anchor bolts.